

Metals

HTH® Metal Remover

Directions for use: (Based on a 50 000l pool)

1. Unplug the automatic pool cleaner
2. With the pump running on circulate/ recirculate/bypass, pour 1 bottle of HTH® Metal remover around the sides of the pool.
3. Allow to circulate for at least 8 hours to ensure thorough mixing.
4. After 8 hours, check and correct the pH is necessary.
5. Reconnect the automatic pool cleaner
6. Allow the filter to run continuously for 24 hours
7. Resume normal chlorination and filtration.
8. If your pool water turns cloudy after using HTH® Metal Remover, add HTH® Sparkle It Cube or HTH® Sparkle It in accordance with label instructions.